

JUMO dTRON 316



JUMO dTRON 308



JUMO dTRON 308



JUMO dTRON 304

JUMO dTRON 304

JUMO dTRON 308

JUMO dTRON 316

Compact Controller
with program function

B 70.3041.1
Operating Instructions

06.05

Contents

1	Preface	3
1.1	Scope of delivery	3
2	Identifying the instrument version	4
3	Mounting	5
3.1	Preparation	5
3.2	Fitting in position, Type 703042/43/44	5
3.3	Fitting in position, Type 703041	5
4	Electrical connection	6
4.1	Connection diagram for Type 703041	6
4.2	Connection diagram for Type 703042/43/44	7
5	Displays and keys	8
6	Operation	9
6.1	Level concept	9
6.2	Level inhibit	10
6.3	Entering values	10
6.4	Entering times	11
6.5	Operation of the fixed-setpoint controller	12
6.6	Operation of the program controller	13
7	Operator level “OPr”	14
8	Parameter level “PArA”	15
9	Configuration level “ConF”	16
9.1	Analog inputs “InP”	16
9.2	Controller “Cntr”	17
9.3	Generator “Pro”	17
9.4	Outputs “OutP”	18
9.5	Display “diSP”	19
10	Autotuning	20
11	Alarms	21

1 Preface



These brief operating instructions only cover those actions that are essential for starting up the controller.

Gray
rastering

The factory settings for the instrument as delivered are shown on a gray background.



The complete configuration options can be found in the comprehensive Operating Manual B 70.3041.0 on the CD, or can be downloaded from <http://www.jumo.net>


1.1 Scope of delivery

- 1 controller
- seal
- mounting brackets
- brief operating instructions
- 1 CD with comprehensive operating instructions and setup program as a demo version

2 Identifying the instrument version

2 Identifying the instrument version

Meaning of the number code on the nameplate:




3 Mounting

3.1 Preparation

Type	dTRON	Panel cut-out
703041	316, in 48mm x 48mm format	45 ^{+0.6} x 45 ^{+0.6} mm
703042/43	308, in 48mm x 96mm format (portrait)/(landscape)	45 ^{+0.8} x 92 ^{+0.8} mm
703044	304, in 96mm x 96mm format	92 ^{+0.8} x 92 ^{+0.8} mm


3.2 Fitting in position, Type 703042/43/44

- * Fit the seal that is supplied onto the instrument body.
- * Insert the controller from the front into the panel cut-out.
- * From behind the panel, slide the mounting brackets into the guides on the sides of the housing.
The flat faces of the mounting brackets must lie against the housing.
- * Push the mounting brackets up to the back of the panel, and tighten them evenly with a screwdriver.



3.3 Fitting in position, Type 703041


- * Fit the seal that is supplied onto the instrument body.
- * Insert the controller from the front into the panel cut-out.
- * From the back of the panel, push the mounting frame onto the instrument body and press it against the back of the panel, compressing the springs, until the latches snap into the notches provided and it is firmly fixed in position.



4 Electrical connection


4 Electrical connection

4.1 Connection diagram for Type 703041




4 Electrical connection

4.2 Connection diagram for Type 703042/43/44



5 Displays and keys




(1)	7-segment display (factory setting: process value) four-digit, red, decimal place is configurable (automatic adjustment on display overflow)
(2)	Active setpoint (factory setting: SP1) SP1, SP2, SP3, SP4 (SP=setpoint); green;
(3)	7-segment display (factory setting: setpoint) four-digit, green, decimal place is configurable; also used for operator prompting (display of parameter and level symbols)
(4)	Keys
(5)	Indication yellow, for <ul style="list-style-type: none"> - switch status of the binary outputs 1 – 6 - ramp/program function is active - manual operation is active
(6)	16-segment display + dim. units two-digit, green; for the unit °C/°F and symbols for h, min, %

Different values can also be visualized on the display.
 ⇒ see the comprehensive operating manual on the CD

6 Operation

6.1 Level concept

The diagram below shows the three instrument levels.



Time-out

If no key is pressed for 30sec, the instrument returns to normal display.

6.2 Level inhibit

The access to the individual levels can be inhibited by entering a code number.

* Press **PGM** and **▼** simultaneously for >5sec to enter the code.

Code	Operator level	Parameter level	Configuration level
0	enabled	enabled	enabled
1	enabled	enabled	inhibited
2	enabled	inhibited	inhibited
3	inhibited	inhibited	inhibited


* Alter code with **PGM** (display blinks)

* Enter code with **▲** and **▼**

* Return to normal display with **EXIT** or automatically after approx. 30sec

6.3 Entering values

When entries are made within the levels, the parameter symbol is shown in the lower display.



* Select parameter with **▲** or **▼**

* Change to the entry mode with **PGM** (lower display blinks)

* Alter value with **▲** and **▼**

The value alters dynamically with the duration of the key stroke.

* Accept the setting with **PGM** or automatically after 2sec


* or

* Cancel entry with **EXIT**.

The value is not accepted.

6.4 Entering times

When entering times (e.g. time of timer), the time unit is shown in addition.



The highest time unit of the display is shown for the unit.

For example, if "h" is shown for the hour, then the time format for the value is hh:mm.

- * Select parameter with **▲** or **▼**
- * Change to the entry mode with **PGM** (lower display blinks)
- * Alter value with **▲** and **▼**
The value alters dynamically with the duration of the key stroke.
- * Accept the setting with **PGM** or automatically after 2sec
or
- * Cancel entry with **EXIT**.
The value is not accepted.

6.5 Operation of the fixed-setpoint controller




The fixed-setpoint controller will only function if

- the fixed-setpoint controller function has been configured ($F_{nct} = 0$)

Normal display



Manual mode



* Alter the present setpoint with **▲** and **▼**

The value is accepted automatically.

The controller output appears in the lower display. The hand symbol and the unit “%” light up in addition.

* Alter the output with **▲** and **▼**

In the case of a modulating controller, the actuator is opened or closed using the keys.

The output entry on a changeover is configurable.

* Return to the normal display with **EXIT** (press for more than 2 seconds)

6.6 Operation of the program controller



The program controller will only function if

- the program controller function has been configured ($F_{nct} = 1 \dots 4$)
- the program setpoints (SPP 1 ... SPP8) and segment times ($t_P^1 \dots t_P^8$) have been entered

Normal display

238.6
SP1 240.0 °C



Program is running

(the symbol for ramp appears)

248.6
SP1 248.7 °C



Selection
OP-
PA-A
Conf

238.6
SP1 240.0 °C

Alter setpoint

* Alter the present setpoint with **▲** and **▼**

The controller controls to the present setpoint.
(The value is accepted automatically after 2 sec.)

Program pause

When the program is paused, the lower display blinks.

248.6
SP1 248.7 °C



Selection
OP-
PA-A
Conf

The program is canceled in the event of a power failure.

7 Operator level “OPr”

Process data *ProC*


Symbol	Meaning
SP 1	Setpoint 1 (editable)
SP 2	Setpoint 2 (editable)
SP 3	Setpoint 3 (editable)
SP 4	Setpoint 4 (editable)
SP _r	Ramp setpoint (only if configured)
InP 1	Measurement of analog input 1
InP2	Measurement of analog input 2 (only if available)
F 1	Calculated result of math formula 1 (only if available)
F2	Calculated result of math formula 2 (only if available)
y	Output
t _{run}	Program run time (only with program controller/generator)
t _{rES}	Residual program time (only with program controller/generator)
t 1	Timer: time 1 (only if configured)
t2	Timer: time 2 (only if configured)

User data *USER* (through the setup program only)

Any parameter (up to eight) can be displayed and edited here by using the setup program.

Program data *Pro* (only with program controller/generator)

A program with up to eight segments is defined here, via the segment setpoints SPP 1...SPP8 and segment times tP 1...tP 8.



8 Parameter level “PArA”

Two parameter sets, PAr1 und PAr2, can be stored.

Parameter	Symbol	Value range	Factory setting
Proportional band 1 ^a	Pb 1	0 ... 9999 °C/°F	0 °C/°F
Proportional band 2 ^b	Pb 2	0 ... 9999 °C/°F	0 °C/°F
Derivative time ^c	dt	0 ... 9999s	80s
Reset time ^d	rt	0 ... 9999s	350s
Actuator time tt	tt	5 ... 3000s	60s
Cycle time 1	CY 1	0.0 ... 999.9s	20s
Cycle time 2	CY 2	0.0 ... 999.9s	20s
Contact spacing	db	0.0 ... 999.9 °C/°F	0 °C/°F
Switching differential 1 ^e	HYS 1	0.0 ... 999.9 °C/°F	1 °C/°F
Switching differential 2	HYS2	0.0 ... 999.9 °C/°F	1 °C/°F
Working point	W	-100 ... +100 %	0 %
Output limiting (max.)	Y1	0 ... 100 %	100 %
Output limiting (min.)	Y2	-100 ... +100 %	-100 %

- a. with Pb1/2=0, the controller structure is not effective; depending on the display configuration, these values are shown with the corresponding decimal places
- b. for controller output 2 (with 3-state controllers)
- c. with dt=0, the controller has no differential action (e. g. PI controller)
- d. with rt=0, the controller has no integral action (e. g. PD controller)
- e. for controllers with Pb1/2=0

9 Configuration level “ConF”

9 Configuration level “ConF”

Depending on the equipment level of the instrument, individual parameters or groups of parameters are switched out of display.

Analog selector

With some parameters, you can choose from a series of analog signals. The list below gives you an overview of the selection options.

- 0 no function
- 1 Analog input 1
- 2 Analog input 2
- 3 Process value (controller)
- 4 Setpoint (controller)
- 5 Ramp end value
- 6 Program setpoint
- 13 Controller output level
- 14 Controller output 1
- 15 Controller output 2

9.1 Analog inputs “InP”

- InP1 Analog input 1 →
- InP2 Analog input 2 →

Parameter	Symbol	Value range
Sensor type	SEnS	0...1...11
Linearization	LIN	0...1...18
Measurement offset	OFFS	-1999...0...+9999
Display start	SCL	-1999...0...+9999
Display end	SCH	-1999...100...+9999

Factory settings are shown **bold**.

Sensor type	
0 no function	6 Heater current 0 – 50mA AC
1 Resistance thermometer in 3-wire circuit	7 0 – 20mA
2 Resistance thermometer in 2-wire circuit	8 4 – 20mA
3 Resistance thermometer in 4-wire circuit	9 0 – 10V
4 Thermocouple	10 2 – 10V
5 Resistance transmitter	11 0 – 1V

9 Configuration level “ConF”

Linearization

0 Linear	10 Thermocouple type U
1 Pt100	11 Thermocouple type L
2 Pt500	12 Thermocouple type K
3 Pt1000	13 Thermocouple type S
4 KTY11-6	14 Thermocouple type R
5 Thermocouple type C	15 Thermocouple type B
6 Thermocouple type D	16 Thermocouple type N
7 Thermocouple type E	17 Thermocouple W3Re-W26Re
8 Thermocouple type T	18 customized linearization
9 Thermocouple type J	

→ In I2 Analog input 1 and 2 general →

Parameter	Symbol	Value range
Temperature unit	Un_t	0...1 (0=°C, 1=°F)
Sampling cycle time	CycL	0...3 (0=50ms; 1=90ms; 2=150ms; 3=250ms)

Factory settings are shown **bold**.

9.2 Controller “Cntr”

Parameter	Symbol	Value range
Controller type	Ctyp	0 no function 1 Two-state controller 2, 3 Three-state, modulating controller 4 Continuous controller
Control action	Act	0...1 (0=direct (cooling); 1=inverse (heating))

Factory settings are shown **bold**.

9.3 Generator “Pro”

Parameter	Symbol	Value range
Function	Fncf	0 Fixed-setpoint controller 1 Ramp function 2 Program controller 3 Program generator 4 Hot-channel controller

Factory settings are shown **bold**.

9 Configuration level “ConF”

9.4 Outputs “OutP”

Numbering of the outputs

Standard: Relay 1 = output 1; relay 2 = output 2; logic output 1 = output 3;
logic output 2 = output 4

Slot	Plug-in board with 1 analog output	Plug-in board with 1 binary output	Plug-in board with 2 binary outputs
Option 1	Output 5	Output 5	Output 5+8
Option 2	Output 6	Output 6	Output 6+9
Option 3	Output 7	Output 7	Output 7+10

→ Analog outputs OutA → Output 5 – 7 OutS...Out7 →

Parameter	Symbol	Value range
Function	Funct	Analog selector switched off
Signal type	S, En	0 ... 2 ... 3 (0 = 0 – 10V; 1 = 2 – 10V; 2 = 0 – 20mA; 3 = 4 – 20mA)
Zero point	OPnt	-1999 ... 0 ... +9999
End value	End	-1999 ... 100 ... +9999

Factory settings are shown **bold**.

9 Configuration level “ConF”

→ Binary outputs OutL → Output 1 – 10 Out 1...Out0 →

Function	
0 no function	16 Limit comparator 4
1 Controller output 1	17 Control contact 1
2 Controller output 2	18 Control contact 2
3 - not used	19 Control contact 3
4 - not used	20 Control contact 4
5 Binary input 1	21 Logic formula 1
6 Binary input 2	22 Logic formula 2
7 Binary input 3	23 Timer 1 active
8 Binary input 4	24 Timer 2 active
9 Binary input 5	25 “Program active” signal
10 Binary input 6	26 Program end signal
11 Binary input 7	27 Tolerance limit signal
12 Binary input 8	28 Manual mode on/off
13 Limit comparator 1	29 Binary marker
14 Limit comparator 2	30 Address value (setup)
15 Limit comparator 3	31 always “active”

9.5 Display “diSP”

→

Parameter	Symbol	Value range
Decimal point	dEcP	0...2 (0 = no decimal place; 1 = one; 2 = two))
Brightness	bri, 6	0...5 (0 = bright)

Factory settings are shown **bold**.

10 Autotuning

The autotuning facility can be used to automatically adapt the controller parameters to the process.

The autotuning function determines the controller parameters for a PID controller or, if dt=0 is set, for a PI controller in a closed control loop.

* Start with ▲ and ▼ (press simultaneously for >2sec)

“tUnE” is shown blinking in the green display



* Cancel with ▲ and ▼ (press simultaneously).



- The more sluggishly the process responds to setpoint changes, the longer the autotuning procedure will take.
- This involves determining the controller parameters rt, dt, Pb1, Pb2, Cy1, Cy2, dF and accepting them automatically after the end of tuning.

11 Alarms

Display	Cause	Clear faults check/rectify/replace
- 1999 (blinking!)	Underrange for the value being displayed.	Is the medium to be measured within the range (too hot - too cold?) Check probe for probe break/short-circuit. Check the probe connection and the terminals. Check the cable.
9999 (blinking!)	OVERRANGE for the value being displayed.	
All displays are on; lower 7-segment display is blinking	Watchdog or power-on triggers initialization (reset).	Replace controller if the initialization takes longer than 5sec.
PrOF	PROFIBUS error	Can be suppressed by setting the PROFIBUS address to "0".
OPt	Hardware configuration error	Check which option boards are installed in the slots.

OVERRANGE/UNDERRANGE covers the following events:

- probe break/short-circuit
- measurement is outside the controllable range for the probe connected
- display overflow

Displaying the software version

* Display version with **PGM** and **■** (press simultaneously).

11 Alarms



Technical data has changed as follows:

Measuring accuracy resistance thermometer Pt100 2-wire	$\leq 0,4\%$
Sensor lead resistance	max. 30Ω per lead for 3-wire or 4-wire circuit
Measuring input for standard signals Resistance transmitter	min. 100Ω , max. $4k\Omega$
Supply voltage for 2-wire transmitter voltage	electrically isolated, not stabilized $30V$ DC with no load $23V$ at $30mA$ load
Electrical safety	to EN 61 010, Part 1 overvoltage category II, pollution degree 2 for type 703041 with power supply AC/DC connect to SELV and PELV only



JUMO GmbH & Co. KG

Street address:

Moltkestraße 13 - 31
36039 Fulda, Germany

Delivery address:

Mackenrodtstraße 14
36039 Fulda, Germany

Postal address:

36035 Fulda, Germany

Phone: +49 661 6003-0

Fax: +49 661 6003-607

e-mail: mail@jumo.net

Internet: www.jumo.net

JUMO Instrument Co. Ltd.

JUMO House

Temple Bank, Riverway
Harlow, Essex CM20 2TT, UK

Phone: +44 1279 635533

Fax: +44 1279 635262

e-mail: sales@jumo.co.uk

Internet: www.jumo.co.uk

JUMO PROCESS CONTROL INC.

885 Fox Chase, Suite 103

Coatesville PA 19320, USA

Phone: 610-380-8002

1-800-554-JUMO

Fax: 610-380-8009

e-mail: info@JumoUSA.com

Internet: www.JumoUSA.com